

TIME IMPACT REUSABLE FLEXIBLE URETEROSCOPES



- **PRE-CLEANING**
 1. Wipe down scope
 2. Transport scope to reprocessing room
 3. Use a syringe to flush channel with cleaning detergent
 - **LEAK TESTING**
 4. Perform a leak test
 - **MANUAL CLEANING**
 5. Immerse scope in cleaning detergent
 6. Use brush to clean surface debris
 7. Use brush to remove debris from working channel
 8. Use a syringe to flush channel with cleaning detergent
 - **RINSING**
 9. Immerse scope in water and wipe down
 10. Use a syringe to flush channel with water
 11. Remove from water and use compressed air down the channel (or flush channel with alcohol)
 - **DRYING**
 12. Completely dry the surface of the scope
 - **STERILIZATION**
 13. Bring to sterilization area
 14. Prepare scope in tray and wrap for sterilization
 15. Sterilize cycle (1-2 hours)
 - **STORAGE**
 16. Bring back to Storage room
- 🕒 **START ALL OVER AGAIN!**

MAINTENANCE CHECKLIST

Traditional Reusable Flexible Ureteroscope vs Uscope Single-Use Flexible Ureteroscope

★	PRE-CLEANING	☆
★	LEAK TESTING	☆
★	MANUAL CLEANING	☆
★	RINSING	☆
★	DRYING	☆
★	STERILIZATION	☆
★	STORAGE	★

Time consuming reprocessing cycle



No reprocessing required!

